Umbrella Style Tool Carousel Spindle Nose
Tool Tip Rapid down ceases at Spindle Nose/Probe trip point machine position + Nose to tool tip distance + buffer distance. From that point, probing commences. Nose to tool tip Buffer Probe Trip Point