



Per 7i77 manual
pg 61 8-32Vdc

Power Supply
12Vdc or 15Vdc
or 19Vdc or 24Vdc



Mesa 7:77 TB2
TB2 pin 1 +V field
TB2 pin 8 GND



Mesa TB8 Connector
TB8 INPUT Pin 1

Hal

```
estop-latch.0.fault-in <=  
hm2-5i25.0.7i77.0.0.input-00  
net remote-estop  
7i77 input.
```